C brick powers itself down.

Published 04/23/2007

Symptom(s):

C brick powers itself down.
Error message:
01/18/07 10:18:58 ALERT: Error reading monitor PIMM1 A interrupt status 1: noacknowledge
01/18/07 10:19:07 ALERT: Error reading monitor PIMM0 A interrupt status 1:arbitration lost
01/18/07 10:19:10 ALERT: Error reading monitor PIMM0 A interrupt status 2: noacknowledge
Error message:
001c16 ALERT: unconfigured power interrupt, monitor: 6, input: 1
001c16 ALERT: unconfigured power interrupt, monitor: 6, input: 2
001c16 ALERT: unconfigured power interrupt, monitor: 6, input: 3

Fact(s):

SGI Origin 3800
SGI Onyx 3400
SGI Onyx 3800
SGI Onyx 3000 Series
SGI Origin 3000 series
SGI 3000 series

SGI Solution:

Replace L1 display cable

Cause(s):

I2C bus problem on L1 display cable

Answers others found helpful

- Onyx350 : How to find Fan 0

Additional Details

Creation Date	04/23/2007 07:37 AM
Last modification	01/15/2016 04:29 PM
Published Date	04/23/2007
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution